## KV-M2140B RM-694

SERVICE MANUAL

French Model Chassis No. SCC-E24C-A



BE-2A CHASSIS

MODELS OF	THE	SAME	SERIES
KV-M2140B			
KV-M1620B			
KV-M1420B			

### **SPECIFICATIONS**

[KV-M2140B]	[	K	V-	М	21	40	BÌ	١
-------------	---	---	----	---	----	----	----	---

Television system

Color system

Channel coverage

Picture tube

Inputs

Outputs

B/G/H VHF: E2-E12

UHF: E21-E69 CABLE TV: S1-S20

VHF: 02-10, B-Q

B/G/H/L

PAL/SECAM

UHF: F21-F69 Black Trinitron tube

90° degree deflection

Approx. 54.5 cm (21 inches)

(Approx.51.0cm picture measured diagonally) Supplied accessories 21-pin connector: CENELEC standard

Including RGB input

Audio/Video input jacks: phono jacks

S-Video input

21-pin connector: CENELEC standard

Headphones jack: minijack

Sound output 5 W (Music) Power consumption

**Dimensions** 

Weight

70.5 Wh

Approx. 513x475x487 mm (w/h/d)

Approx. 24.9 kg

[RM-694]

Remote control system infrared control

Power requirements

Accessories supplied

3V dc

2 batteries IEC designation

R6 (size AA)

**Dimensions** Approx.  $55 \times 18 \times 185$ mm (w/h/d)

Weight

Approx. 100g including batteries

IEC designation R6 batters (2)


RM-694 Remote Commander (1) IEC designation R6 batteries (2)

Design and specifications are subject to change without notice.





### 21-pin Euro Connector Configuration



PIN	SIGNAL	SPECIFICATION
1	Audio output	0.5Vrms/1kilohm or less
2	Audio input	0.5Vrms/10kilohms or more
თ	Audio output	0.5Vrms/1kilohm or less
4	Earth (audio)	
5	Earth (B-input)	
6	Audio input	0.5Vrms/10kilohms or more
7	B-input	0.7Vp-p/75ohms
8	Function switching	9.5V to 12V
9	Earth (G-input)	
10		
11	G-input	0.7Vp-p/75ohms
12		
13	Earth (R-input)	
14	Earth (blanking)	
15	R-input	0.7Vp-p/75ohms
16	Fast blanking	1V to 3V/75ohms
17	Earth (video)	
18	Earth (fast blanking)	
19	Video output	IVp-p/75ohms
20	Video input	IVp-p/75ohms
21	Screening plug	

### 4 pin connector ( )

Pin No	Signal Signal level
1	Ground
2	Ground
3	Y (S signat) input 1V ± 3dB 75ohm, positive Sync 0.3V: da dB
4	C (S signal) input 0.3V ± 3dB 75ohm positive

### SAFETY-RELATED COMPONENT WARNING!

COMPONENTS IDENTIFIED BY SHADING AND MARK A ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

### **TABLE OF CONTENTS**


Sect	ion <u>Title</u> <u>Page</u>
1.	GENERAL
1-1.	Index of the Parts4
1-2.	To Preset Channels5
1-3.	Daily Use of the TV5
1-4.	Picture and Sound Adjustments6
2.	DISASSEMBLY
2-1.	Rear Cover Removal7
2-2.	Service Position7
2-3.	Picture Tube Removal8
3.	SET-UP ADJUSTMENTS
3-1.	Beam Landing9
3-2.	Convergence10
3-3.	Focus12
3-4.	Screen (G2) and White Balance12
4.	CIRCUIT ADJUSTMENTS
4-1.	A Board Adjustments

### **GENERAL**


### 1-1. INDEX OF THE PARTS

In the following you will find a short description of the parts and their function on the set or on the remote commander using the respective symbols. For more details reter to the page number given in the index.


TV Set - Front



TV Set - Rear



Remote Commander



### TV set

Symbol	Function	
C	Headphones jack (mini-jack)	
٧ <del>(}</del>	Video input jack	
A €	Audio input jack	
<b>+</b> /-	Buttons for Sound and picture adjustment	
+/-	Programme scanning buttons	
<b>⊕</b>	S-video input jack	
Ф	Standby indicator	
0	Power switch	
٦٢	Aerial socket (rear of the set)	
Ö	21-Pin connector (rear of the set)	

### Remote Commander

Symbol	Function
M	Mute button
1-9, 0, -/	Number buttons — in case of two digit numbers first press button —/—— and then two number buttons
*	Button has no function
•	Select button for picture adjustment item
+/-	Buttons for adjustment picture items
†and +/−	Buttons for manual fine tuning of a channel
→•←	Button for resetting the picture adjustment items to standard
С	Button for clearing a programme position (in preset mode)
+	Functions only in combination with other buttons
-  nd ↑	Preset mode on/off buttons
Ф	Buttons for switching the TV set into standby mode
0	Used to return to TV-mode from stadby and video input modes
G	Button for selecting the video input mode
0	On/off button for onscreen display
PROGR +/-	Programme scanning butlons
△+/-	Buttons for adjusting the volume
0	Button for activating the sleep timer

Buttons not referred to in this index have no function.

### 1-2. TO PRESET CHANNELS

The control buttons to preset channels are located on the Remote Commander. (Up to 60 programme positions are at your disposal.)

- 1 Press the power switch on the set to switch it
- 2 Press both the + (shift) button and the -> (preset) button simultaneously. You are now in the preset mode.
- 3 Use either button PROGR + (upwards) or PROGR - (downwards) to select the required programme position.

TRINITRON RM-694

UHF IIIIIIIIIIII

UHF IHIIHIII --

UHF MIMILION---

5

flashes.

Indicates the

approximate location

in the band of the

channel being tuned

Programme number

stops flashing.

On-screen display

after presetting.

- Press both the + button and the + or button repeatedly until the desired TV station is found.
- Repeat steps 3 and 4 for all other channels.
- Press once more both the + button and the ->> (preset) button in order to return to the TV mode and to store the channels.

### Skipping of programme positions

Using both the button C and the + button you have the possibility to skip unused programme positions (e.g. without a stored station) when pressing the PROGR +/- buttons.


- 1 Press both the + button and the (preset) button to select the preset mode.
- Select the programme position to be skipped by pressing the + or - PROGR button.
- Press the C button.
- Prees both the (preset) button and the + button to return to the TV mode.

### **Manual Fine Tuning**

If the reception of a channel is not satisfactory you have the possibility to deactivate the Automatic Fine Tuning which usually tunes in the best possible picture during presetting. Press both the + button and the + or button to fine ture the channel. By pressing the respective programme number the automatic Fine Tuning will be restored.

### 1-3. DAILY USE OF THE TV

Your TV set is supposed to be operated with the Remote Commander, for the basic functions however it is also possible to use the buttons on the set itself.



Switching the set on

Press the power switch on the set to switch the TV on, if the set is switched on, the green indicator on the set lights up, if it is in standby mode the red indicator lights up (see also 'Standby mode').

### · Switching the set off

Press the power switch on the set to switch the TV off.

Press the respective number button 1,2, ---9 on the remote commander.

In the case of two digit numbers, first press button -/-- and then the two respective number buttons.

With the PROGR +/- buttons you can scan the programme positions (+ upwards, downwards).

### On the Set

Press the - button for lower programme positions and the + button for higher ones.

### Standby mode

There are two possibilities to put the set into standby mode.

### 1. Directly

Press the button O on the remote commander. The red indicator (1) on the set lights up.

### Note:

Use the standby button only for short breaks if the set will not be used for a longer time span, use the power switch () to switch the set off.

### 2. By using the sleep timer

Press the 4 button repeatedly until the required time period is displayed on the screen (30, 60, 90 or 0 for cancelling of the operation).

In this way you can select the time period after which the set switches itself automatically into standby mode.

### Switching the set on out of standby mode

PROGR (1)

Press the button or one of the number buttons on the remote commander.

### On-screen display


Press the button to display the programme number on the screen and press the button once more to make it disappear.

### · Selecting the signal of the connected device

Press the 4 button to receive the signal of the device (e.g. a video recorder) connected at the V A connectors or the 21 -pin connector (rcar of the set). Press the button to return to the TV mode.



### 1-4. PICTURE AND SOUND ADJUSTMENTS



Volume

Press the button  $\triangle$  + to increase the volume and the button  $\triangle$  - to decrease it.

### On the set

Press the ⊕button until ∠ is displayed on the screen and adjust the volume with the - or + button.

Modification of the picture presettings
 Press the ⊕ button on the commander to select either contrast ♠, colour intensity ♠, or brightness ☒ (the respective indication is displayed on the screen). Adjust the settings by pressing the + or - button.

To return to factory-set levels

Press the reset button → • ← to return to
the preset picture leves.


### On the set

Press the button in order to select the requested item (contrast), colour intensity in brightness it, and adjust with the + or − button.

Muting the sound

Press the button to switch off the sound.


Press the button again to restore the sound.




Ó


### SECTION 2 DISASSEMBLY

### 2-1. REAR COVER REMOVAL




### 2-2. SERVICE POSITION






### REMOVING PROCEDURES



① Turn up one side of the rubber cap in ② Using a thumb pull up the rubber cap the direction indicated by the arrow ③. firmly in the direction indicated by the arrow ⑤.




When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ©.

### · HOW TO HANDLE AN ANODE-CAP

- ① Don't hurt the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to hurt inside of anode-caps!
  - A material fitting called as shatter-hook terminal is built in the rubber.
- ③ Don't turn the foot of rubber over hardly! The shatter-hook terminal will stick out or hurt the rubber.





### SECTION 3 SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted. The controls and switch below should be set as follows unless otherwise noted:
  - ◆ CONTRASTcontrol ······ 80%(or Normal by commander)

☼ BRIGHTNESS control .... 50%

Perform the adjustments in order as follows:

### Preparation:

- Set the side of the unit with the PICTUE TUBE so that it faces east or west in order to reduce the influence of external magnetic force.
- Turn the power switch for the unit ON and erase the magnetic force using a degausser..

### 3-1. BEAM LANDING

Demagnetize with a degausser

- Input a raster signal with the pattern generator.
   CONTRAST BRIGHTNESS
- 2. Turn the raster signal of the pattern generator to red
- Move the deflection yoke backward, and adjust with the purity control so that red is in the center and blue and green are at the sides evenly. (Fig.3-1 - 3-3)
- 4. Move the deflection yoke forward, and adjust so that the entire screen becomes red. (Fig.3-1)
- 5. Switch over the raster signal to blue and green confirm the condition.
- 6. When the position of the deflection yoke is determined, tighten it with a deflection yoke mounting screw.
- 7. When landing at the corner is not right, adjust by using the disk magnets. (Fig.3-4)




Fig.3-1

- 1. Beam Landing
- 2. Convergence
- 3. Focus
- 4. Screen (G 2) and White Balance

Note: Test Equipment Required.

- 1. Color bar/Pattern Generator
- 2. Degausser
- 3. DC Power Supply
- 4. Digital multimeter
- 5. Oscilloscope




Fig.3-2






Fig.3-3




### 3-2. CONVERGENCE

### Preparation:


- Before starting, perform FOCUS, H.SIZE, and V.
   SIZE adjustments.
- Set BRIGHTNESS control to minimum.
- Feed in the dot pattern.
- (1) Horizontal and Vertical Static Convergence



- 1. Adjust H.STAT VR to converge red, green and blue dots the in center of the screen. (Horizontal movement)
- 2. Adjust V. STAT magnet to converge red, green and blue dots in the center of the screen. (Vertical movement)
- 3. If the red, green and blue dots do not converge on the center of screen with H.STAT VR, perform horizontal convergence adjustment using H.STAT VR and V.STAT magnet as shown below. (In this case, H.STAT VR and V.STAT magnet effect each other.)
- Tilt the V.STAT magnet and adjust static convergence to open or close the V.STAT magnet.



4. When the V.STAT magnet is moved in the direction of arrow (2) and (3), red, green and blue dots move as shown below.




If the red and blue dot do not converge with green dots, perform following steps.

Move BMC magnet (a) to correct insufficient H.static convergence.

Rotate BMC magnet (b) to correct insufficient V.static convergence.


In either case, repeat Beam Landing Adjustment.




### (2) Dynamic Convergence Adjustment Preparation:

- Before starting perform Horizontal and Vertical static convergence Adjustment.
- 1. Slightly loosen deflection yoke screw.
- 2. Remove deflection yoke spacers.


- 3. Move the deflection yoke for best convergence as shown below.
- 4. Tighten the deflection yoke screw.
- 5. Install the deflection yoke spacers.





### **3-3. FOCUS**

Adjust FOCUS so that the whole screen is in best focus.




### White Balance Adjustment

- 1. Input all-white signal from the pattern generator.
- 2. Adjust the BRIGHTNESS and COLOR controls to the standard level.
- 3. Adjust the following using RV 704 (B DRIVE) and RV 703 (G DRIVE)

In the following adjustments, the CONTRAST, COLOR and BRIGHTNESS controls are set to normal unless otherwise specified.

### 3-4. SCREEN (G 2) and WHITE BALANCE




### Screen (G 2) Setting

- 1. Input dot signal from the pattern generator.
- 2. Set the picture BRIGHTNESS control to minimum level.
- 3. Apply 170 V DC to the cathodes of R,G and B from an external power source.
- 4. While watching the picture, adjust the G2 control RV701 (SCREEN) immediately before fly-back line disappears.

### SECTION 4 CIRCUIT ADJUSTMENTS

### 4-1. A BORAD ADJUSTMENTS




-Component side-


### TU AGC Adjustment (RV 503)

- 1. Tune in air signal.
- 2. Adjust AGC VR (RV 503) so that snow-noise and cross-modulation just disappear from the picture.

### RV 504 H.CENT (HORIZONTAL CENTER)




### **RV 801 H.SIZE (HORIZONTAL SIZE)**




### **RV 501 V.CENT (VERTICAL CENTER)**



### RV 505 V.SIZE (VERTICAL SIZE)




### RV 802 PIN AMP (PINCUSHION AMPLIFIER)



### H.FREQ Adjustment (RV 502)

- 1. Input a PAL COLOR BAR signal, then connect an electrolytic capacitor (100  $\mu/16$  V) between pin and GND of IC 502.
- 2. Adjust RV 502 (H.FREQ) to stop scrolling of the picture in the horizontal direction.
- 3. After adjustment, remove the electrolytic capacitor.




### REF OSC 8.8 MHz Adjustment (CT 332)

- 1. Input a PAL COLOR BAR pattern.
- 2. Short circuit between pin of IC 331 and ground.
- 3. Adjust CT 332 to obtain color synchronizetion.
- 4. Remove the jumper wire from IC 331.


### BELL FILTER Adjustment (LV 301)

- 1. Input a SECAM COLOR BAR pattern.
- 2. Connect an oscilloscope to rhe Q 302 emitter.
- 3. Adhust LV 301 so that waveform becomes flat.



### SECAM DISCRI Adjustment (RV 331 R-Y L 331 B-Y)


- 1. Input a SECAM COLOR BAR pattern.
- 2. Connect an oscilloscope to pin ① of IC 301.
- 3. Adjust RV 331(R-Y) so that white and black parts of the waveform of pin ① becomes 0 lecel.
- 4. Connect an oscilloscope to pin 3 of IC 301.
- 5. Adjust L 331(B-Y) so that white and black parts of the waveform of pin 3 becomes 0 level.



KV-M2140B RM-694

### CHARACTER POSITION Adjustment (RV 001)

- 1. Input PAL COLOR BAR pattern.
- 2. Adjust RV 001 to position the charcter display at the point indicated by the arrow below.



## KV-M2140K/M2141K

### SERVICE MANUAL



### **OIRT** Model

KV-M2140K

Chassis No. SCC-E50B-A

KV-M2141K

Chassis No. SCC-E50A-A

BE-2A CHASSIS

MODELS OF THE	E SAME SERIES
KV-M2140K/M2141K	

### **SPECIFICATIONS**

[KV-M2140K/M2141K]

Television system

Color system

Channel coverage

B/G/H

VHF: E2-E12

UHF: E21-E69

B/G/H/D/K

PAL/SECAM

CABLE TV: S1-S20

D/K

VHF: R1-R12

UHF: R21-R60

Picture tube

Black Trinitron tube

90° degree deflection

Approx. 54.5 cm (21 inches)

(Approx.51.0cm picture measured diagonally)

Inputs

21-pin connector: CENELEC standard

Including RGB input

Audio/Video input jacks: phono jacks

S-Video input

Outputs

21-pin connector: CENELEC standard

Headphones jack: minijack

Sound output

5 W (Music)

Power consumption

70.5Wh (KV-M2140K)

73.5Wh (KV-M2141K)

**Dimensions** 

Approx. 513x475x487 mm (w/h/d)

Weight

Approx. 24.9 kg

[RM-694]

Remote control system infrared control

Power requirements

Supplied accessories

3V dc

2 batteries IEC designation

R6 (size AA)

**Dimensions** 

Weight

IEC designation R6 batters (2)

Approx.  $55 \times 18 \times 185$ mm (w/h/d) Approx. 100g including batteries

Accessories supplied

RM-694 Remote Commander (1)

IEC designation R6 batteries (2)


Design and specifications are subject to change without

notice.

TRINITRON® COLOR TV SONY



### 21-pin Euro Connector Configuration



PIN	SIGNAL	SPECIFICATION
1	Audio output	0.5Vrms/1kilohm or less
2	Audio input	0.5Vrms/10kilohms or more
3	Audio output	0.5Vrms/1kilohm or less
4	Earth (audio)	
5	Earth (B-input)	
6	Audio input	0.5Vrms/10kilohms or more
7	8-input	0.7Vp-p/75ohms
8	Function switching	9.5V to 12V
9	Earth (G-input)	
10		
11	G-input	0.7Vp-p/75ohms
12		
13	Earth (R-input)	
14	Earth (blanking)	
15	R-input	0.7Vp-p/75ohms
16	Fast blanking	1V to 3V/75ohms
17	Earth (video)	
18	Earth (fast blanking)	
19	Video output	1Vp-p/75ohms
20	Video input	1Vp-p/75ohms
21	Screening plug	

4 pin cont	nector $(\mathfrak{S}_{+})$ .	
Pin No	Signal	Signal level
1	Ground	
2	Ground	
3	Y (S signal) input	1V ± 3dB 75ohm, positive Sync 0.3V; dB
4	C (S signal) input	0.3V ± 3dB 75ohm positive

### SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY SHADING AND MARK A ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

### TABLE OF CONTENTS

Seci	<u>tion</u> <u>Title</u>	Page
1.	GENERAL	
1-1.	Index of the Parts	4
1-2.	To Preset Channels	5
1-3.	Daily Use of the TV	5
1-4.		
1.5.	Viewing Teletext (KV-M2141K only)	6
2.	DISASSEMBLY	
2-1:	Rear Cover Removal	7
2-2.	Service Position	7
2-3.	V Board Removal (KV-M2141K only)	7
2-4.	Picture Tube Removal	8
3.	SET-UP ADJUSTMENTS	
3-1.	Beam Landing	
<b>3-</b> 2.	Convergence	
3-3.	Focus	
3-4.	Screen (G2) and White Balance	12
4.	CIRCUIT ADJUSTMENTS	
4-1.		
4-2.	V Board Adjustment (KV-M2141K only)	14
5.	DIAGRAMS	
5-1.	Circuit Boards Location	16
5-2.	Schematic Diagrams and Printed Wiring Boards	17
5-3.	Semiconductors	27
6.	EXPLODED VIEW	28
7.	FI FCTRICAL PARTS LIST	29

The layout, etc., will be slightly different from the operating instructions packed with SECTION 1 GENERAL Note)

# 1-1. INDEX OF THE PARTS

In the following you will find a short description of the parts and their function on the set or on the remote commander using the respective symbols. For more details reter to the page number given in the index.

TV Set - Front

Buttons for Sound and picture adjustment

-/+ (1)

<del>-</del>/+

٤

Э Θ -

> (4) <u>ላ</u>

Audio input jack Video input jack

Headphones jack (mini-jack)


Function

Symbol

TV set

Programme scanning buttons


S-video input jack Standby indicator



Remote Commander

TV Set — Rear





21-Pin connector (rear of the set)

**(b)**:

Aerial socket (rear of the set)

Power switch

Select button for picture adjustment item

Button has no function


Buttons for adjustment picture items

-/+

**(** 

00 0

땋



Used to return to TV-mode from stadby and video input modes Buttons for switching the TV set into standby mode Button for selecting the video input mode ψ Ð 0

Preset mode on/off buttons

◆ and ↑

On/off button for onscreen display Buttons for adjusting the volume Programme scanning butlons PROGR +/-7+7 (\*)


Note Buttons not referred to in this index have no function.


Button for activating the sleep timer

**1** 

RM-694

TRINITRON





# 1-2. TO PRESET CHANNELS

The control buttons to preset channels are located on the Remote Commander. (Up to 60 programme positions are at your disposal.)

- Press the power switch on the set to switch it
- Press both the \* (shift) button and the -(preset) button simultaneously. You are now in the preset mode ~
- PROGR (downwards) to select the required Use either button PROGR + (upwards) or programme position. ന

On-screon display

during channel

operation.

preset

TRINITRON RM-694

- button repeatedly until the desired TV station Press both the + button and the is found. 4
- Repeat steps 3 and 4 for all other channels. S
- Press once more both the T button and the (preset) button in order to return to the TV mode and to store the channels. ဖ

Using both the button C and the ↑ button you have the possibility to skip unused programme positions (e.g. without a stored station) when pressing the PROGR +/- buttons. Skipping of programme positions

- Press both the ★ button and the ♣ (preset) button to select the preset mode.
- Select the programme position to be skipped by pressing the + or - PROGR button.
- Press the C button.
- Prees both the ﴿ (preset) button and the \* button to return to the TV mode.

# Manual Fine Tuning

Automatic Fine Tuning which usually tunes in the respective programme number the automatic Fine button to fine ture the channel. By pressing the If the reception of a channel is not satisfactory Press both the T button and the + or you have the possibility to deactivate the best possible picture during presetting. Tuning will be restored.

# 1-3. DAILY USE OF THE TV

Your TV set is supposed to be operated with the Remote Commander, for the basic functions however it is also possible to use the buttons on the set itself.

# Switching the set on

Press the power switch on the set to switch the indicator on the set lights up, if it is in standby TV on, if the set is switched on, the green mode the red indicator lights up (see also Standby mode')

# Switching the set off

ψ

0 0

Number Buttons 1, 2 ... 9, 0--/-

- PROGR +/-

++-(1)

000

1,2,...9,0

<u>-</u>/-

ÐQ

Press the power switch on the set to switch the

# ح off.

-PROGR +/-

9

Press the respective number button 1,2, 9 on the remote commander. Selection of programmes

In the case of two digit numbers, first press button -/-- and then the two respective number buttons.

With the PROGR +/- buttons you can scan the programme positions (+ upwards, -downwards).

## On the Set

8N-694

TRINITROM

Programme position

flashes.

positions and the + button for higher ones. Press the - button for lower programme

There are two possibilitles to put the set into standby mode. Standby mode

## Directly

approximate location channel being tuned

Indicates the

UHF IIIIIIIIII ----

in the band of the

Press the button O on the remote commander. The red indicator O on the set lights up. Note:

Use the standby button only for short breaks if the set will not be used for a longer time span, use the power switch (1) to switch the set off.

# By using the sleep timer

UHF IIIIIIIIIIIIIIIIIII

required time period is displayed on the screen Press the @ button repeatedly until the (30, 60, 90 or 0 for cancelling of the

In this way you can select the time perlod after which the set switches itself automatically into standby mode. operation).

# Switching the set on out of standby mode

O - On screen display after presetting.

Ð

PROGR

Programme number

stops flashing.

UHF IIIIIIIII----

Press the igcup button or one of the number buttons on the remote commander.


# Press the Joutton to display the programme number on the screen and press the button On-screen display

Time feature (KV-M2141K only) In TV-mode, if teletext is broadcast on the selected channel, press the button @to display the once more to make (only for KV-M2141K) it disappear. current time.

# Selecting the signal of the connected device

Press the Gbutton to receive the signal of the device (e.g. a video recorder) connected at the V & A connectors or the 21 -pin connector (rcar of the set).

# 1-4. PICTURE AND SOUND ADJUSTMENTS



Press the button \( \section \) to increase the volume

Press the Dutton until A is displayed on and the button 
d → to decrease it. On the set

the screen and adjust the volume with the -Press the Tubutton on the commander to Modification of the picture presettings or + button.

# brightness (the respective indication is displayed on the screen). Adjust the settings by select either contrast (), colour intensity (3), or

pressing the + or - button.

Press the reset button →·← to return to To return to factory-set leveis the preset picture leves.

requested item (contrast(), colour Intensity (3), brightness ∜, and adjust with the + or − Press the button [ in order to select the On the set

## Muting the sound

Press the X button to switch off the sound. Press the button again to restore the sound.

To view the teletext service, use the Remote Commander. RM-694 has teletext buttons indicated in green teletext operation are indicated in green. Operation

- 1 Select the TV channel for the desired teletext
- teletext service. Once 闺/┛ has been pressed, the TV channel
- the number buttons, if an error is made, complete the three digit sequence by keying in any digit. Then re-enter the correct page number. The cannot be changed. Key in the three digits for the desired page using requested teletext page is displayed.

To return to the TV mode, press TV on the Remote Commander. The teletaxt service can be displayed directly from the standby mode. by pressing (E)(E)

- To receive the teletext service of a different TV
  - Press TV to return to the TV mode. Select the desired TV channel. Press (第八色).
- To display the index page. Press (E) (INDEX). If the necessary signal is not being broadcast, page 100 is displayed.

To access the next or preceding page Press (B) (PAGE+) or (G) (PAGE-).
These buttons are indicated in white on the Commander.

To superimpose the teletext display on the TV picture. Press (2) (2) twice from TV mode. Press (2) (2) again to return to the TEXT display.

displayed.
Press (B) (TEXT CL). This button can be operated from both the TEXT and MIX displays. To suppress the teletext display so that the TV picture is

To prevent a teletext page (subpage) from being updated /changed. Press ⑮ HOLD. The HOLD symbol "⑱" appears at the top eft of the screen.



1-5. VIEWING TELETEXT (KV-M2141K only)

To enlarge the teletext display. Press (B). Press Once to enlarge the upper half of the display: press again to enlarge the lower half of the display; press again to return to the normal display.

To reveal concealed information such as the answers to a

Press (3) (REVEAL)

Press again to conceal the answers.

To adjust the contrast of the teletaxt display. Press  $\mathbf{O} + \mathbf{o} \mathbf{r} - \mathbf{b} \mathbf{u} \mathbf{t} \mathbf{o} \mathbf{n}$ .

To watch the TV program while weiting for a requested

page to be displayed.

Request the new page.

Press (S) to watch the TV program. The requested page number spears at the top left of the screen. When the requested page has been found, the page number is displayed on the top left hand corner of the



To view this page, press 🖹 🗷

To have a requested page displayed at a pre-determined

"T \* \* \* \* will appear at the bottom of the screen. 1 Request a time coded page (e. g. alarm page). 2 Press [© (TP ON).




Enter your request time with the number buttons, using four digits. For example, 07:30. m



To watch the TV program until the requested time, press  $(\mathbb{R})$  At the requested time, the page number will be displayed at the top of the screen. To view this page, press  $(\mathbb{R}/\mathbb{Z})$ . To cancel the request, first ensure that the teletext page is displayed, then press  $(\mathbb{R}/\mathbb{Z})$ .


### SECTION 2 DISASSEMBLY


### 2-1. REAR COVER REMOVAL




### 2-2. SERVICE POSITION

### 2-3. V BOARD REMOVAL (KV-M2141K only)






### - REMOVING PROCEDURES



① Turn up one side of the rubber cap in ② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow ⑤.





When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ©.

### · HOW TO HANDLE AN ANODE-CAP

- ① Don't hurt the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to hurt inside of anode-caps! A material fitting called as shatter-hook
- ② Don't turn the foot of rubber over hardly! The shatter-hook terminal will stick out or hurt the rubber.

terminal is built in the rubber.





## SECTION 3 SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted. The controls and switch below should be set as follows unless otherwise noted:
  - ◆ CONTRASTcontrol ······ 80%(or Normal by commander)

☼ BRIGHTNESS control .... 50%

Perform the adjustments in order as follows:

### Preparation:

- Set the side of the unit with the PICTUE TUBE so that it faces east or west in order to reduce the influence of external magnetic force.
- Turn the power switch for the unit ON and erase the magnetic force using a degausser..

### 3-1. BEAM LANDING

Demagnetize with a degausser

1. Input a raster signal with the pattern generator.

 $\frac{\text{CONTRAST}}{\text{BRIGHTNESS}}$   $\left.\right\}$  normal

- 2. Turn the raster signal of the pattern generator to red.
- 3. Move the deflection yoke backward, and adjust with the purity control so that red is in the center and blue and green are at the sides evenly. (Fig. 3-1 - 3-3)
- 4. Move the deflection yoke forward, and adjust so that the entire screen becomes red. (Fig.3-1)
- 5. Switch over the raster signal to blue and green confirm the condition.
- When the position of the deflection yoke is determined, tighten it with a deflection yoke mounting screw.
- 7. When landing at the corner is not right, adjust by using the disk magnets. (Fig.3-4)




Fig.3-1

- 1. Beam Landing
- 2. Convergence
- 3. Focus
- 4. Screen (G 2) and White Balance

Note: Test Equipment Required.

- 1. Color bar/Pattern Generator
- 2. Degausser
- 3. DC Power Supply
- 4. Digital multimeter
- 5. Oscilloscope




Fig.3-2






Fig.3-3




### 3-2. CONVERGENCE

### Preparation:


- Before starting, perform FOCUS, H.SIZE, and V.
   SIZE adjustments.
- Set BRIGHTNESS control to minimum.
- Feed in the dot pattern.
- (1) Horizontal and Vertical Static Convergence



- 1. Adjust H.STAT VR to converge red, green and blue dots the in center of the screen. (Horizontal movement)
- Adjust V. STAT magnet to converge red, green and blue dots in the center of the screen. (Vertical movement)
- 3. If the red, green and blue dots do not converge on the center of screen with H.STAT VR, perform horizontal convergence adjustment using H.STAT VR and V.STAT magnet as shown below. (In this case, H.STAT VR and V.STAT magnet effect each other.)
- Tilt the V.STAT magnet and adjust static convergence to open or close the V.STAT magnet.



4. When the V.STAT magnet is moved in the direction of arrow (and (b), red, green and blue dots move as shown below.




If the red and blue dot do not converge with green dots, perform following steps.

Move BMC magnet (a) to correct insufficient H.static convergence.

Rotate BMC magnet (b) to correct insufficient V.static convergence.


In either case, repeat Beam Landing Adjustment.




### (2) Dynamic Convergence Adjustment Preparation:

- Before starting perform Horizontal and Vertical static convergence Adjustment.
- 1. Slightly loosen deflection yoke screw.
- 2. Remove deflection yoke spacers.


- 3. Move the deflection yoke for best convergence as shown below.
- 4. Tighten the deflection yoke screw.
- 5. Install the deflection yoke spacers.





### **3-3. FOCUS**

Adjust FOCUS so that the whole screen is in best focus.




### White Balance Adjustment

- 1. Input all-white signal from the pattern generator.
- 2. Adjust the BRIGHTNESS and COLOR controls to the standard level.
- 3. Adjust the following using RV 704 (B DRIVE) and RV 703 (G DRIVE)

In the following adjustments, the CONTRAST, COLOR and BRIGHTNESS controls are set to normal unless otherwise specified.

### 3-4. SCREEN (G 2) and WHITE BALANCE




### Screen (G 2) Setting

- 1. Input dot signal from the pattern generator.
- 2. Set the picture BRIGHTNESS control to minimum level.
- 3. Apply 170 V DC to the cathodes of R,G and B from an external power source.
- 4. While watching the picture, adjust the G2 control RV701 (SCREEN) immediately before fly-back line disappears.

## SECTION 4 CIRCUIT ADJUSTMENTS

### 4-1. A BORAD ADJUSTMENTS




A BOARD -Component side-


### TU AGC Adjustment (RV 503)

- 1. Tune in air signal.
- 2. Adjust AGC VR (RV 503) so that snow-noise and cross-modulation just disappear from the picture.


### RV 504 H.CENT (HORIZONTAL CENTER)




### RV 801 H.SIZE (HORIZONTAL SIZE)




### RV 501 V.CENT (VERTICAL CENTER)



### RV 505 V.SIZE (VERTICAL SIZE)




### RV 802 PIN AMP (PINCUSHION AMPLIFIER)



### H.FREQ Adjustment (RV 502)

- 1. Input a PAL COLOR BAR signal, then connect an electrolytic capacitor (100  $\mu/16$  V) between pin and GND of IC 502.
- 2. Adjust RV 502 (H.FREQ) to stop scrolling of the picture in the horizontal direction.
- 3. After adjustment, remove the electrolytic capacitor.



### REF OSC 7.16 MHz Adjustment (CT 331)


- 1. Input an NTSC COLOR BAR pattern.
- 2. Short circuit between pin @ of IC 331 and ground.
- 3. Adjust CT 331 to obtain color synchronization.
- 4. Remove the jumper wire from IC 331.

### REF OSC 8.8 MHz Adjustment (CT 332)

- 1. Input a PAL COLOR BAR pattern.
- 2. Short circuit between pin of IC 331 and ground.
- 3. Adjust CT 332 to obtain color synchronization.
- 4. Remove the jumper wire from IC 331.


### BELL FILTER Adjustment (LV 301)

- 1. Input a SECAM COLOR BAR pattern.
- 2. Connect an oscilloscope to rhe Q 302 emitter.
- 3. Adhust LV 301 so that waveform becomes flat.




### SECAM DISCRI Adjustment (RV 331 R-Y L 331 B-Y)

- 1. Input a SECAM COLOR BAR pattern.
- 2. Connect an oscilloscope to pin ① of IC 301.
- 3. Adjust RV 331(R-Y) so that white and black parts of the waveform of pin ① becomes 0 lecel.
- 4. Connect an oscilloscope to pin 3 of IC 301.
- 5. Adjust L 331(B-Y) so that white and black parts of the waveform of pin 3 becomes 0 level.




### CHARACTER POSITION Adjustment (RV 001)

- 1. Input PAL COLOR BAR pattern.
- 2. Adjust RV 001 to position the charcter display at the point indicated by the arrow below.



### 4-2. V BOARD ADJUSTMENT

(KV-M2141K only)




### RGB LEVEL Adjustment (RV 01)

- 1. Set PICTURE to maximum.
- 2. Adjust RV01 till the RGB output becomes maximum.

### **SECTION 5 DIAGRAMS**

### 5-1. CIRCUIT BOARDS LOCATION



Reference information

: ALT

: ALR

METAL FILM RESISTOR : RN SOLID : RC NONFLAMMABLE CARBON : FPRD NONFLAMMABLE FUSIBLE : FUSE NONFLAMMABLE WIREWOUNO : RS NONFLAMMABLE CEMENT : RB ADJUSTMENT RESISTOR : \* MICRO INDUCTOR : LF-8L COIL TANTALUM CAPACITOR : TA STYROL : PS POLYPROPYLENE : PP : PT MYLAR METALIZED POLYESTER : MPS METALIZED POLYPROPYLENE : MPP BIPOLAR : ALB

HIGH TEMPERATUNE

HIGH RIPPLE

Note: The components identified by shading and mark A are critical for safety. Replace only with part number specified.

- All capacitors are in  $\mu F$  unless otherwise noted. pF :  $\mu \mu F$ 50WV or less are not indicated except for electrolytics.
- Indication of resistance, which does not have one for rating electrical power is as follows.


Pitch Rating electrical power: 1/4W

- Chip resistor is in 1/10W.
- All resistors are in ohms.  $k\Omega$ : 1000 $\Omega$ ,  $M\Omega$ : 1000 $k\Omega$ .
- - : nonflammable resistor.
- fusible resistor.
- panel designation and adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- All voltage are in V.
- $\bullet$  Readings are taken with a  $10M\Omega$  digital multimeter.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerances.
- = : B+ bus.
- signal path. (RF)

### 5-2. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

- A Board -

TI		Q307	B-6	Đ501	Ð-3 E-4	CC	II
		0310	A-3	£503	_	LY301	C-7
10001	Ð-9	0311	A-3	9504 9511	G-2 B-3	L331	C-6
10002	Ð-9	Q401 Q457	B-2 D-1	Đ519	C-8	2331	
10003	Ð-10	Q501	B-4	£513	F-7		
10004	E-9		B-3	£602	F-6		
10005	B-8	Q502 Q503	B-3	£603	F-5		
IC101 IC102	B-2 B-5	Q504	C-3	£603	E-4		
IC201	F-8	Q505	B-3	£605	E-6		
10301	Đ-5	Q601	G-5	£605	Đ-5		
10302	B-7	Q801	G-4	€607	G-5		
10331	C-7	Q802	H-3	£608	H-5		
10501	Ð-2	Q803	F-3	Đ609	G-5	1 1 1 1 1 1	
10502	C-4	Q1301	B-9	£610	G-5	100	
10601	G-5	Q1302	B-10	9611	F-4		
10801	F-3	01303	B-10	£801	G-3		
10802	E-4	01304	A-10	Đ802	H-4	-	
10002		01305	A-10	Đ803	G-4		
		01306	B-10	£805	G-1		
	10700			£806	F-1		
RAN5	ISTOR			£807	F-3		
QQ01	Ð-8	DIC	חר	£808	E-3		
0003	C-9	DIG	JUE	£809	9-1		
0004	Ð-10	Đ002	E-10	Đ820	F-4		
0005	B-8	Đ004	C-9	Ð1301	B-10		
0006	C-8	900g	B-3	£1302	B-10		
Q007	B-4	Đ007	B-8	Đ1303	B-10		
0015	Đ-3	800G	Ð-10	Ð1304	A-10	10 4	
0016	9-10	£009	B-8	Đ1305	A-10		
Q017	E-9	Đ020	B-8	Đ1306	B-10		
0019	Ð-10	Ð101	C-2	£1307	B-10		
0020	Ð-8	Ð102	C-1			200	
0101	C-2	Ð103	C-1				
Q102	C-1	Ð105	B-2				
0103	C-1	Ð110	C-5	VARI	ABLE		
Q104	C-1	Đ301	C-6				
0106	A-2	Đ302	A-2		STOR		
Q107	A-2	Đ303	B-6	RV001	Ð-9	1	
0108	C-2	Đ305	A-2	RV331	C-6		
0109	B-1	Đ306	B-6	RV501	Ð-2		
0110	B-1	Đ313	A-3	RV502	B-4		
0111	B-1	Đ321	C-5	RV503	C-4		
0112	A-7	Đ324	A-7	RV504	B-4		
G113	B-5	Đ333	Ð-7	RV505	Ð-2		
0114	B-5	Đ402	A-1	RV801	F-4		
0115	A-6	Đ403	B-1	RV802	E-2	1	
Q123	A-2	9404	B-1	1 6			
0140	C-2	Đ405	A-2				
0141	C-3	Đ406	C-1			-	
0302	C-7	Đ410	A-1	TRI	MMER		
0303	C-7	9411	A-1			-	
0304	B-6	Đ417	Ð-1	CT331	C-7		
Q305 Q306	B-6 B-6	Đ418 Đ426	A-4 C-1	CT332	C-7		



KV-M2140K/M2141K RM-694 KV-M2140K/M2141K

SYSTEM CONTROL, A/V OUT, H/V OUT, MEMORY, CHROMA








### NOTE:


The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.


### 5-2. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS























— V Board — (KV-M2141K ONLY)










#### 5-3. SEMICONDUCTORS



사고 (14년년) - , 47년 2월 년


### **SECTION 6 EXPLODED VIEW**

#### NOTE:

- · Items with no part number and no des-
- Terms with no part number and no description are not stocked because they are seldom required for routine service.
   The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark 🐧 are critical for safety. Replace only with part number specified. 

#### ■: BVTP4×16 7-685-663-79



REF.NO. PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
7 4-382-733-01 8 3-704-495-01 9 1-452-277-00 10 A 1-451-295-11 1 A-1638-016-A 12 *4-379-167-01 13 *4-379-160-01 14 4-200-433-01	DOOR ASSY (KV-M2140K ONLY) CABINET ASSY (WITH BEZEL ASSY) (B CATCHER, PUSH J1 BOARD SPEAKER PICTURE TUBE (A51JXH60X) SCREW (S), PT SPACER, DY MAGKET, BMC DEFLECTION YOKE (Y21PFA2) C BOARD, COMPLETE COVER (MAIN), CV COVER (REAR LID), CV SPRING, EXTENSION COIL, DEMAGNETIZATION		3 19	1-571-433-12 A-1632-056-A 1-439-416-51 1-465-541-11 *9-910-999-33 4-389-201-02 1-590-460-11 4-308-870-00 1-452-032-00 1-452-094-00 X-4309-608-0 3-701-007-00	BUTTON, POWER ESWITCH, PUSH (AC PC A BOARD, COMPLETE TTRANSFORMERITASSY, F ITUNER (BT 3C 301) PLATE, INSULATION HOLDER, AC CORD CORD, POWER (WITH C CLIP, LEAD WIRE MAGNET, DISK: 10MM MAGNET, ROTATABLE I PERMALLOY ASSY, CON BAND, BINDING Y BOARD, COMPLETE	CONNECTOR)

### **SECTION 7 ELECTRICAL PARTS LIST**

#### NOTE:

- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- · All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

When indicating parts by reference number, please include the board name.

CAPACITORS • MF : µF, PF : µµF COILS

• MMH : mH, UH : µН

The components identified by shading and mark A are critical for safety. Replace only with part number

specified.

RESISTORS

All resistors are in ohms
 F: nonflammable

REF.NO. PART NO.	DESCRIPTION		REMARK		. PART NO.	DESCRIPTION			REMARK
A-1630-060-A	A1 BOARD, COMPLETE			 	A-1632-056-A	A BOARD, COM			
	SOCKET, CONNECTOR 6P				*4-341-752-01	SPACER, IC HOLDER, LED EYELET EYELET SPRING			
C1111 1-163-103-00 C1112 1-163-103-00 C1113 1-163-103-00 C1114 1-163-103-00 C1115 1-163-017-00	CERAMIC CHIP 27PF CERAMIC CHIP 27PF	5% 5% 5% 5% 10%	50V 50V 50V 50V 50V	; ; ; ; ; ; ; ; ;	*4-389-343-01	5 1			
C1117 1-164-005-11	CERAMIC CHIP 0.47MF CERAMIC CHIP 0.47MF CERAMIC CHIP 0.47MF MYLAR 0.0082MF ELECT 47MF	10% 20%	25V 25V 25V 400V 16V	C001 C002 C003 C004 C005	1-126-101-11 1-106-220-00 1-164-232-11 1-123-382-00 1-126-103-11	CERAMIC CHIP	100MF 0.1MF 0.01MF 3.3MF 470MF	20% 10% 20% 20%	16V 100V 50V 50V 16V
C1154 1-164-232-11	CERAMIC CHIP 0.01MF CERAMIC CHIP 0.01MF	10% 10% 10%	100V 50V 50V	C006 C007 C009 C010 C012	1-124-907-11	ELECT ELECT CERAMIC CHIP	10MF 10MF	5% 20% 20% 5% 20%	50V 50V 50V 50V 50V
	TER> DISCRIMINATOR, CERAMIC			C018 C020	1-164-232-11 1-124-903-11	CERAMIC CHIP	0.01MF	20%	50V 50V
CF1111 1-527-840-00 CF1112 1-567-570-11	FILTER, CERAMIC			C021 C022 C023	1-124-907-11 1-124-907-11 1-124-907-11	ELECT ELECT	10MF 10MF 10MF	20% 20% 20%	50V 50V 50V
<con< td=""><td>NECTOR&gt;</td><td></td><td></td><td>C024 C025</td><td>1-124-907-11 1-126-233-11</td><td>ELECT FLECT</td><td>10MF 22MF</td><td>20% 20%</td><td>50V 50V</td></con<>	NECTOR>			C024 C025	1-124-907-11 1-126-233-11	ELECT FLECT	10MF 22MF	20% 20%	50V 50V
CNA111*1-568-877-51				C026 C030 C037	1-124-903-11 1-124-903-11	ELECT	IMF IMF	20% 20%	50V 50V 50V
<1C> IC1101 8-759-003-90			!	C038 C039	1-163-009-11 1-163-117-00	CERAMIC CHIP CERAMIC CHIP	0.001MF 100PF	10% 5%	-50V 50V
IC1102 8-752-006-12	IC CX20061			C041 C055	1-124-478-11 1-163-075-00	ELECT CERAMIC CHIP	100MF 0.047MF	20%	25V . 50V
<001	L> ·			C058	1-163-077-00 1-164-232-11			10%	25V 50V
L1108 1-408-410-00 L1111 1-408-411-00 L1112 1-408-409-00	INDUCTOR 15UH			C062 C063 C101 C102	1-126-101-11	ELECT CERAMIC CHIP ELECT	100MF	20% 10% 20% 20%	16V 50V 16V 50V
<res< td=""><td>ISTOR&gt;</td><td></td><td></td><td>C103 C104</td><td>1-163-105-00 1-164-665-11</td><td>CERAMIC CHIP CERAMIC CHIP</td><td>33PF 0.039MF</td><td>5% 10%</td><td>50V 50V</td></res<>	ISTOR>			C103 C104	1-163-105-00 1-164-665-11	CERAMIC CHIP CERAMIC CHIP	33PF 0.039MF	5% 10%	50V 50V
R1111 1-216-033-00 R1112 1-216-033-00	METAL GLAZE 220 5%	1/10W 1/10W 1/10W	i	C105 C106 C107	1-164-665-11 1-164-232-11 1-124-477-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.039MF 0.01MF 47MF	10%	50V 50V 16V
R1113 1-216-083-00 R1152 1-216-057-00 R1153 1-216-045-00	METAL GLAZE 2/K 5% METAL GLAZE 2.2K 5% METAL GLAZE 680 5%	1/10W 1/10W 1/10W		C112				5% 5%	507
The state of the s	METAL GLAZE 4.7K 5% METAL GLAZE 1K 5%	1/10W 1/10W		C114 C115	1-163-109-00 1-163-129-00 1-164-232-11	CERAMIC CHIP CERAMIC CHIP	330PF 0.01MF	5 <b>%</b>	50V 50V

### KV-M2140K/M2141K RM-694



REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
C120 C123	1-163-173-00 1-163-117-00 1-124-917-11	CERAMIC CHIP					1-162-568-11	CERAMIC CHIP		10%	16V
C125 C128 C131	1-163-009-11	ELECT CERAMIC CHIP CERAMIC CHIP	0.001MF	20% 10%	50V 50V 50V	C341 C343 C344 C345	1-130-783-00 1-163-187-00	MYLAR MYLAR CERAMIC CHIP	0.33MF 0.047MF 0.33MF 180PF	10% 10% 10% 5%	100V 100V 100V 50V
C132 C133 C135 C136	1-164-232-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01MF 0.022MF	10%	50V 50V 50V 50V	C346 C347 C348	1-163-037-11 1-163-037-11	CERAMIC CHIP	0.022MF 0.022MF	10% 10%	50V 25V 25V
C139	1-164-232-11	CERAMIC CHIP	0.01MF	10% 10%	50V 50V	C349 C351 C352	1-163-037-11 1-106-375-12 1-106-375-12	CERAMIC CHIP MYLAR	0.022MF 0.022MF 0.022MF	10% 10% 10%	25V 250V 250V
C140 C141 C142 C143 C144	1-163-017-00 1-163-017-00 1-163-809-11	CERAMIC CHIP	0.0047MF 0.0047MF 0.047MF	10% 10% 10% 10%	50V 50V 25V 50V	C353 C354 C355 C355 C356	1-163-037-11 1-163-037-11 1-163-037-11	CERAMIC CHIP CERAMIC CHIP	0.022MF 0.022MF 0.022MF	10% 10% 10%	25V 25V 25V 25V 50V
C145 C146	1-163-809-11	CERAMIC CHIP CERAMIC CHIP	0.047MF	10% 10%	25V 25V	C357	1-164-232-11	CERAMIC CHIP	0.01MF		50 <b>V</b>
C147 C148 C149	1-163-809-11 1-164-665-11 1-126-101-11	CERAMIC CHIP CERAMIC CHIP ELECT	0.039MF 100MF	10% 10% 20%	25V 50V 16V	C358 C359 C360 C361	1-124-556-11 1-163-125-00 1-124-903-11 1-163-103-00	CERAMIC CHIP	1MF	20% 5% 20% 5%	16V 50V 50V 50V 50V
C151 C154 C157	1-164-232-11 1-124-927-11	ELECT CERAMIC CHIP ELECT	10MF 0.01MF 4.7MF	20%	50V 50V 50V	C363 C364	1-163-137-00	CERAMIC CHIP	680PF	5% 5%	50V
C201 C202	1-126-233-11	ELECT ELECT	22MF 2.2MF	20% 20%	50V 50V	C367 C370	1-164-232-11	CERAMIC CHIP ELECT MYLAR ELECT	0.01MF	20% 10%	50V 50V 100V
C203 C204		CERAMIC CHIP ELECT CERAMIC CHIP	470MF	10% 20% 10%	50V 25V 50V	C401 C403	1-124-910-11 1-163-133-00			20% 5%	50V 50V
C206 C207 C208	1-163-011-11 1-124-925-11 1-126-104-11	ELECT	2.2MF	20%	50V 35V	C404 C429	1-164-232-11 1-163-197-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01MF 470PF	10%	50V 50V 25V
C209 C210	1-124-910-11 1-106-228-00	ELECT MYLAR	470MF 47MF 0.22MF 10MF 0.01MF	20% 10%	50V 100V	C430 C431	1-124-910-11	ELECT	47MF	20%	50Ý 50Y
C301 C302 C303	1-124-907-11 1-163-059-00 1-163-059-00			20%	50V 50V 50V	: C434	1-126-233-11 1-164-232-11	CERAMIC CHIP ELECT CERAMIC CHIP	22MF 0.01MF	20%	25V 50V
C304 C305		CERAMIC CHIP	0.1MF 47MF	20%	25V 50V	C475 C476	1-126-233-11 1-106-216-00		22MF 0.068MF	20% 10%	50V 100V
C306 C307 C308	1-106-220-00 1-163-038-00	MYLAR CERAMIC CHIP ELECT	0.1MF 0.1MF 47MF		100V 25V 50V		1-124-910-11 1-163-205-00 1-163-181-00 1-163-005-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	100PF 470PF	20% 10% 5% 10%	50V 50V 50V 50V
	1-163-099-00 1-124-917-11	CERAMIC CHIP ELECT CERAMIC CHIP	33MF	5% 20% 5%	50V 50V 50V	C503	1-163-181-00 1-124-122-11	CERAMIC CHIP	100PF	5% 20%	50V
C311 C312 C313		CERAMIC CHIP	150PF	5% 5%	50V 50V	C505 C506	1-126-233-11 1-106-228-00	ELECT MYLAR	22MF 0.22MF 1000MF	20% 10% 20%	50V 100V 25V
C314 C315	1-163-103-00 1-163-427-91	CERAMIC CHIP	68PF	5% 5%	50V 50V	C507 C508	1-124-557-11 1-163-117-00	ELECT CERAMIC CHIP	100PF	5%	50V
C316 C317 C318	1-163-117-00 1-163-093-00 1-164-232-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	100PF 10PF	5% 5% 10%	50V 50V 50V	C509 C510 C511	1-162-568-11 1-163-081-00 1-163-117-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.22MF	10% 5%	16V 25V 50V
C319	1-163-038-00	CERAMIC CHIP	0.1MF	10%	25V	C511 C512 C513	1-106-216-00 1-124-927-11	MYLAR	0.068MF 4.7MF	10% 20%	100V 50V
C321 C323 C329	1-163-038-00 1-163-055-00 1-131-367-00	CERAMIC CHIP CERAMIC CHIP TANTALUM	0.0047MF 22MF	10% 10%	25V 50V 16V	C514 C515	1-136-298-00 1-163-035-00	FILM CERAMIC CHIP	0.0033MF 0.047MF	5% 5%	100V 50V 50V
C330 C331	1-163-117-00 1-124-927-11	CERAMIC CHIP	4.7MF	5% 20%	50V 50V	C516 C517 C518	1-163-113-00 1-163-033-00 1-163-117-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.022MF	5%	50V 50V 50V
C332 C333 C334	1-130-783-00 1-163-037-11 1-163-063-00	MYLAR CERAMIC CHIP CERAMIC CHIP	0.33MF 0.022MF 0.022MF	10% 10% 10%	100V 25V 50V	C520 C521	1-163-033-00 1-131-377-00	CERAMIC CHIP	10MF	10%	50V 10V
C335		CERAMIC CHIP	0.022MF	10% 5%	50V 50V	C524 C525 C526	1-106-228-00 1-106-216-00 1-124-910-11	MYLAR MYLAR ELECT	0.22MF 0.068MF 47MF	10% 10% 20%	100V 100V 50V
C337 C338	1-130-834-00 1-106-220-00	MYLAR MYLAR	1MF 0.1MF	10% 10%	63V 100V	C527 C529	1-164-232-11	CERAMIC CHIP	0.01MF	10% ST	50V
C339	1-106-220-00	MYLAR	0.1MF	10%	100V		1-105-117-00	CERAMIC CHII			

Α

The components identified by shading and mark  $\triangle$  are critical for safety.

Replace only with part number specified.

÷.								
REF.NO. PART NO.	DESCRIPTION			REMARK	REFINO.	PART NO.	DESCRIPTION	REMARK
C530 1-163-197-00 ( C532 1-163-117-00 ( C536 1-124-927-11 E C537 1-163-038-00 ( C540 1-216-295-00 E	CEMPILLE CHILL O	170PF 100PF 1.7MF	5% 5% 20% 1/10W	50V 50V 50V 25V	CNA11 CNA12 CNA21	<pre><com *1-506-947-11="" *1-560-290-00<="" *1-568-877-51="" pre=""></com></pre>	NECTOR> PIN, CONNECTOR 6P PIN, CONNECTOR 2P PLUG, CONNECTOR (2.5MM PITCH) PIN, CONNECTOR 3P	
C601 <u>A</u> 1-161-964-61 C602 <u>A</u> 1-161-964-61 C603 1-162-599-12 C604 1-125-318-00 EC605 1-161-754-00 C605	CERAMIC 0 CERAMIC 0 ELECT(BLOCK) 2	).0047MF ).0047MF 220MF	20%	250V 250V 250V 400V 2KV	CNA42 CNA43 CNA61 CNA62	*1-565-394-11 *1-565-394-11 *1-508-765-00 *1-580-844-11	PIN, BOARD TO BOARD CONNECTOR PIN, BOARD TO BOARD CONNECTOR PIN, CONNECTOR (5MM PITCH) 3P PIN, CONNECTOR (POWER) PIN, CONNECTOR (5MM PITCH) 2P	
C606 1-136-637-11 F C607 1-106-367-00 M C608 1-161-753-00 C C609 1-124-347-00 E C610 1-124-557-11 E	MYLAR O CERAMIC 4 ELECT 1	0.01MF 170PF .00MF	10% 10% 10% 20% 20%	630V 400V 3KV 160V 25V	CNA64 CNA81	*1-508-784-00 *1-508-768-00	PIN, CONNECTOR (5MM PITCH) 1P PIN, CONNECTOR (5MM PITCH) 6P PLUG (MINIATURE DY) 6P	
C612 1-102-228-00 C	CERAMIC 4	TOPF	10%	500V		<tri< td=""><td>MMER&gt;</td><td></td></tri<>	MMER>	
C614 1-126-101-11 E C616 A 1-164-246-11 C C618 1-126-233-11 E C621 A 1-136-517-11 F	ELECT 1 CERAMIC 0 ELECT 2	00MF 0.0022MF	20% 20%	16V 400V 50V 300V		1-141-418-11 1-141-418-11		
С623 <u>А</u> . 1-164-246-11	CERAMIC O	.0022MF	20%	400V		<dio< td=""><td>DE&gt;</td><td></td></dio<>	DE>	
	CERAMIC CHIP 1 CERAMIC CHIP 1 CERAMIC CHIP 2	5PF 5PF 20PF	5% 5% 5%	300V 50V 50V 50V	D002 D004 D007 D008 D009	8-719-914-44		
C801 1-101-821-00 C C802 1-102-244-00 C C804 1-126-101-11 E C805 A.1-136-080-11 F C806 1-136-187-11 F	CERAMIC 2 GLECT 1 FILM 0	00MF .011MF	10% 20% 3%	500V 500V 16V 2KV 250V	D020 D101 D102 D103	8-719-911-19 8-719-110-03 8-719-110-03		
C807 A 1-161-731-51 C C808 1-136-933-11 F C809 1-102-212-00 C C811 1-136-540-11 F C812 1-124-634-11 E	TILM 1. CERAMIC S. TILM 0	MF 20PF .82MF	5% 10% 5%	2KV 100V 500V 160V 250V	D104 D110 D301 D302	8-719-400-18 8-719-109-85 8-719-914-44 8-719-800-76	DIODE MA152WK  DIODE RD5.1ES-B2 DIODE DAP202K DIODE 1SS226	
C813 1-163-009-11 C C814 1-126-542-11 E C815 1-126-233-11 E C816 1-102-228-00 C	LECT 4 LECT 2:	.7MF	20% 20%	50V 160V 50V 500V	D303 D305 D306 D313	8-719-800-76 8-719-400-18 8-719-800-76	DIODE DAP202K DIODE 1SS226 DIODE MA152WK DIODE 1SS226	
C817 1-123-948-00 E C818 1-106-375-12 M			20% 10%	250V 250V	D321 D324 D331	8-719-914-44	DIODE RD5.6ES-B2 DIODE DAP202K DIODE 1SS119	
C820 1-162-318-11 C C821 1-126-101-11 E C822 1-162-318-11 C	ERAMIC 0 LECT 10 ERAMIC 0	.001MF 00MF ; .001MF	10% 20% 10%	2KV 500V 16V 500V	D332 D333 -D334 D402 D403	8-719-911-19 8-719-914-44 8-719-109-97	DIODE 1SS119 DIODE 1SS119 DIODE DAP202K DIODE RD6.8ES-B2 DIODE RD6.8ES-B2	
C824 1-124-913-11 E C825 1-106-371-00 M	LECT 4° IYLAR 0° LECT 0°	70MF .015MF .47MF	20% 10% 20%	50V 400V 50V 16V	D404 D405 D406 D411	8-719-109-97 8-719-110-09 8-719-110-09	DIODE RD6.8ES-B2 DIODE RD8.2ES-B3 DIODE RD8.2ES-B3 DIODE RD6.8ES-B2	
C1301 1-164-232-11 C C1302 1-126-101-11 E C1303 1-163-809-11 C C1304 1-163-809-11 C	LECT 10 ERAMIC CHIP 0.	00MF 2 .047MF 3	20% 10%	50V 16V 25V 25V	D417 D418	8-719-914-44 8-719-914-44 8-719-911-19	DIODE DAP202K DIODE DAP202K DIODE 1SS119	
C1306 1-163-005-11 C	LECT 23	2MF 2	20%	50V 50V	D427 D450	8-719-911-19 8-719-978-31	DIODE ÎSSÎÎ9 DIODE DTZ6.8-TT11 DIODE RU-3AM	
<pre></pre>	R> ISCRIMINATOR, RAP, CERAMIC	CERAMIC			D504 D519 D601	8-719-400-18 8-719-400-18 8-719-946-90	DIODE 1SS119 DIODE MA152WK DIODE MA152WK DIODE KRUUTI-6088	
CF502 1-409-327-00 TI SWF101 1-409-327-00 TI	RAP, CERAMIC ( RAP, CERAMIC (	(6.5MHZ) (6.5MHZ)		1 1 1	D603	8-719-911-55	DIODE RGP02-17 DIODE UO5G	÷ •



The components identified by shading and mark A are critical for safety.

Replace only with part number specified.

REF.NO. PART NO.	DESCRIPTION .	REMARK	REF.NO.	PART NO.			REMARK	<b>(</b>
D605 8-719-300-33 D606 8-719-980-78	DIODE ERD28-08S DIODE RU-3AM DIODE ERAS3-006		L107	1-408-410-00 1-410-872-21	INDUCTOR INDUCTOR	12UH 10UH		
D607 8-719-300-33 D608 8-719-300-33 D609 8-719-911-55	DIODE RU-3AM DIODE RU-3AM DIODE UOSG		L301 L302 L303 L331	1-408-409-00 1-408-419-00 1-408-425-00 1-404-554-11	INDUCTOR INDUCTOR	10UH 68UH 220UH		
D610 8-719-911-55 D611 8-719-312-40 D801 8-719-945-80 D802 8-719-928-08	DIODE ERD28-08S DIODE RU-3AM DIODE ERAS3-006 DIODE RU-3AM DIODE RU-3AM DIODE RU-3AM  DIODE U05G DIODE U05G DIODE ERC06-15S DIODE ERC08-15S DIODE ERC28-08S  DIODE RU-3AM		L404 L405 L406	1-408-397-00 1-408-409-00 1-408-417-00	INDUCTOR INDUCTOR	1UH 10UH 47UH		
D805 8-719-300-33 D806 8-719-976-64	DIODE RU-3AM DIODE RU-3AM DIODE RGP02-17		L501 L502 L801	1-404-493-00 1-408-405-00 1-407-365-00	INDUCTOR COIL, CHOKE	4.7UH		
D807 8-719-300-33 D808 8-719-300-33 D809 8-719-400-18	DIODE RU-3AM DIODE RU-3AM DIODE MA152WK		L802 L804 L805 L806	*1-420-872-00 1-459-390-00 1-459-105-21 1-459-652-12	COIL (WITH CO	ORE)		
D820 8-719-911-19 D1301 8-719-911-19 D1302 8-719-911-19 D1303 8-719-911-19	DIODE 1SS119 DIODE 1SS119 DIODE 1SS119 DIODE 1SS119		L1001	1-408-239-00 1-408-226-00 1-408-397-00	INDUCTOR INDUCTOR	4.7MMH 82UH 1UH 1UH		
	DIODE MA152WK DIODE 1SS226		LIUUZ	1-408-397-00 <var< td=""><td>IABLE COIL&gt;</td><td>100</td><td></td><td></td></var<>	IABLE COIL>	100		
D1307 8-719-800-76	DIODE 1SS226		LV301	1-404-554-11	COIL			
<del< td=""><td>AY LINE&gt;</td><td></td><td>i i i</td><td>&lt;10</td><td>LINK&gt;</td><td></td><td></td><td></td></del<>	AY LINE>		i i i	<10	LINK>			
DL301 1-236-062-11 DL1301 1-415-613-11	AY LINE> MODULE, Y DELAY LINE DELAY LINE, Y		PS801 <u>∧</u>	. 1-532-637-91	LINK, IC 1A		rande still	
<fus< td=""><td></td><td></td><td>i  </td><td><tra< td=""><td>NSISTOR&gt;</td><td></td><td></td><td></td></tra<></td></fus<>			i 	<tra< td=""><td>NSISTOR&gt;</td><td></td><td></td><td></td></tra<>	NSISTOR>			
1-533-230-11	FUSE, GLASS-TUBE (TIME-LAG) 3.15/ HOLDER, FUSE; F601 COVER, FUSE; F601	A/250V	Q001 Q003 Q004 Q005 Q006	8-729-920-74 8-729-901-01 8-729-920-74 8-729-923-54 8-729-922-66	TRANSISTOR 25 TRANSISTOR DT	C144EK SC2412K-QR A143TK		
<1C>			0007	8-729-920-74	TRANSISTOR 2S	C2412K-OR		
1C002 8-759-988-32 1C003 8-749-922-13 1C004 8-759-805-37	IC PCA84C840P-BE2A3 IC ST24C02CP IC KEY-COOSV-F IC L78LR05D-MA IC UPC574J		Q016   Q017	8-729-920-74 8-729-901-47 8-729-216-22 8-729-901-06	TRANSISTOR DT TRANSISTOR 2S	A143EK A1162-G		
IC102 8-759-044-41 IC201 8-759-502-74 IC301 8-759-505-39	IC TDA3827-V3 IC TDA7245 IC TDA4660V2		Q020 Q101 Q102 Q103	8-729-901-47 8-729-901-47 8-729-901-47	TRANSISTOR DT TRANSISTOR DT	A143EK A143EK A143EK	en e	
1C302 8-759-512-04 1C331 8-759-521-22	IC TDA3505-V1 IC TDA4650/V4		Q104 Q106	8-729-920-74 8-729-920-74	TRANSISTOR 2S			
IC501 8-759-113-05 IC502 8-759-515-72 IC601 8-749-901-65 IC801 8-759-945-58	IC UPC1488H IC TDA8304 IC STR54041 IC RC4558P		Q107 Q112 Q114 Q115	8-729-216-22 8-729-920-74	TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR DT TRANSISTOR DT	C2412K-QR C124EK		
1C802 8-759-604-39	1C M5F78M12L		Q141 Q302	8-729-920-74	TRANSISTOR BF TRANSISTOR 2S	C2412K-QR		
<jac J401 1-561-534-00</jac 	SOCKET 21P		Q303 Q304 Q305	8-729-920-74	TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S	C2412K-QR		
J1401 1-563-500-11	JACK BLOCK, PIN (L TYPE) 2P			8-729-901-00 8-729-216-22	TRANSISTOR DT TRANSISTOR 2S			
	INDUCTOR 10UH		Q310 Q311	8-729-920-74 8-729-216-22	TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S	C2412K-QR A1162-G		
L102 1-408-409-00 L103 1-408-399-00 L106 1-408-415-00	INDUCTOR 10UH INDUCTOR 1.5UH INDUCTOR 33UH		Q457 Q504	8-729-216-22 8-729-920-74				

# KV-M2140K/M2141K RM-694

_	
Δ	
	١.

REF.NO.	PART NO.						PART NO.					REMARK
Q505 Q601 Q801 Q802 Q803	8-729-216-22 8-729-906-74 8-729-119-80 8-729-925-64 8-729-202-03	TRANSISTOR 2SA TRANSISTOR BC6 TRANSISTOR 2SC TRANSISTOR BU5 TRANSISTOR 2SD	1162-G 37-16 2688-LK 08AS2 1408-Y		1 2 3 1 1 1	JR126 JR127 JR128 JR129 JR130	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5% 5% 5% 5%	1/8W 1/8W 1/8W 1/8W 1/8W	
Q1301 Q1302 Q1303 Q1304 Q1305	8-729-216-22 8-729-901-06 8-729-901-01 8-729-920-74 8-729-901-01	TRANSISTOR 2SD TRANSISTOR 2SA TRANSISTOR DTA TRANSISTOR DTC TRANSISTOR DTC TRANSISTOR DTC TRANSISTOR DTC  ISTOR>	1162-G 144EK 144EK 2412K-QR 144EK			JR131 JR133 JR134 JR135 JR136	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5% 5% 5% 5%	1/8W 1/8W 1/8W 1/8W 1/8W	
Q1306	8-729-901-01	TRANSISTOR DTC	144ЕК		1	JR137 JR139 JR144	1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0	5% 5% 5%	1/8W 1/8W 1/8W 1/8W	
JR44	- KES 1-216-295-00	METAL GLAZE	0 5% 1.	/10W		JR147	1-216-296-00	METAL GLAZE	ő	.5%	1/8W	
JR99 JR003 JR004 JR005	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	ISTOR> METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 1 0 5% 1 0 5% 1 0 5% 1	/10W /10W /10W /10W /10W		JR148 JR149 JR150 JR151 JR151	1-216-296-00 1-216-296-00 1-216-296-00 1-216-295-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0	5% 5% 5% 5%	1/8W 1/8W 1/8W 1/10W 1/8W	,
JR006 JR009 JR010 JR011 JR012	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 1. 0 5% 1. 0 5% 1. 0 5% 1. 0 5% 1.	/10W /10W /10W /10W /10W		JR152 JR152 JR153 JR155 JR181	1-216-295-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5% 5% 5% 5%	1/10W 1/8W 1/8W 1/8W 1/8W	
		METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 1, 0 5% 1, 0 5% 1, 0 5% 1, 0 5% 1,	/10W /10W /10W /10W /10W		JR182 JR183 JR184 JRC38	1-216-296-00 1-216-296-00 1-216-296-00 1-216-295-00 1-216-069-00	METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0 6.8K	5% 5% 5%	1/8W 1/8W 1/8W 1/10W 1/10W	
JRO20 JRO26 JRO27 JRO28 JRO29	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE		/10W /10W /10W /10W /10W		R003 R004 R005	1-216-081-00 1-216-081-00 1-216-083-00 1-216-206-00 1-216-254-00	METAL GLAZE METAL GLAZE METAL GLAZE	22K 22K 27K 2.2K 220K		1/10W 1/10W 1/10W 1/8W 1/8W	
JRO34 JRO36 JRO37	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE  METAL GLAZE  METAL GLAZE  METAL GLAZE  METAL GLAZE  METAL GLAZE	0 5% 1/ 0 5% 1/ 0 5% 1/	/10W /10W /10W /10W /10W		R008 R009 R010	1-216-190-00 1-216-049-00 1-216-049-00 1-216-198-00 1-216-035-00	METAL GLAZE METAL GLAZE METAL GLAZE	470 1K 1K 1K 270	5% 5% 5%	1/8W 1/10W 1/10W 1/8W 1/10W	
JRO39 JRO45 JRO50 JRO51 JRO52	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE (	5% 1/ 5% 1/ 5% 1/ 5% 1/ 5% 1/	/10W /10W /10W /10W /10W		KUID	1-216-248-00 1-216-077-00 1-216-748-11 1-216-230-00 1-216-049-00	METAL GLAZE	120K 15K 39K 22K 1K	5% 5% 5% 5%	1/8W 1/10W 1/10W 1/8W 1/10W	
JR101 JR102 JR103	1-216-295-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	) 5% 1/ ) 5% 1/ ) 5% 1/	/10W /8W /8W /8W		RO18 RO19 RO20	1-216-081-00 1-216-065-00 1-216-065-00 1-216-065-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	22K 4.7K 4.7K 4.7K 1K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
JR106 JR107 JR108	1-216-296-00	METAL GLAZE COMETAL GLAZE	) 5% 1/ ) 5% 1/ ) 5% 1/	/8W /8W /8W /8W		R023 R024 R025	1-216-051-00 1-216-065-00 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 1.2K 4.7K 100K 47K	5% 5% 5%	1/8W 1/10W 1/10W 1/10W 1/10W	
JR111 JR116 JR117	1-216-296-00 1-216-296-00	METAL GLAZE COMETAL GLAZE	5% 1/ 5% 1/ 5% 1/ 5% 1/ 5% 1/	(8W (8W (8W (8W		R028 R029 R030 R031	1-216-085-00 1-216-041-00 1-216-077-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	33K 470 15K 10K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
JR121 JR122 JR123	1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE OMETAL GLAZE OMETAL GLAZE OMETAL GLAZE OMETAL GLAZE OMETAL GLAZE	5% 1/ 5% 1/ 5% 1/ 5% 1/	8W 8W 8W		R033 R034	1-216-057-00 1-216-238-00	METAL GLAZE METAL GLAZE METAL GLAZE	2.2K 47K	5%	1/10W 1/8W 1/10W	



_									•					
	REF.NO.	PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
	R038 R040 R041 R042 R043	1-216-073-00 1-216-081-00 1-216-081-00 1-216-081-00 1-215-900-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL OXIDE	10K 22K 22K 22K 22K 22K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 2W		1	1-216-295-00 1-216-041-00 1-216-057-00 1-216-295-00 1-216-037-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 470 2.2K 0 330	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R044 R045 R046 R047 R048	1-216-105-00 1-216-089-00 1-216-081-00 1-216-079-00 1-216-202-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220K 47K 22K 18K 1.5K		1/10W 1/10W 1/10W 1/10W 1/8W		R141 R142 R143 R144 R147	1-216-021-00 1-216-063-00 1-216-033-00 1-216-065-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	68 3.9K 220 4.7K 10K	5% %%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R049 R050 R052 R053 R054	1-216-073-00 1-216-250-00 1-216-065-00 1-216-049-00 1-249-395-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE CARBON	10K 150K 4.7K 1K 15	24	1/10W 1/8W 1/10W 1/10W 1/4W		R148 R149 R151 R152 R153	1-216-017-00 1-216-182-00 1-216-057-00 1-216-061-00 1-215-867-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL OXIDE	47 220 2.2K 3.3K 470	5% 5% 5%	1/10W 1/8W 1/10W 1/10W 1W	
	R055 R056 R058 R059 R060	1-216-057-00 1-216-041-00 1-249-434-11 1-216-089-00 1-216-234-00	METAL GLAZE METAL GLAZE CARBON METAL GLAZE METAL GLAZE	2.2K 470 27K 47K 33K	5% 5% 5% 5%	1/10W 1/10W 1/4W 1/10W 1/8W		R199 R201 R202 R203 R204	1-216-073-00 1-216-057-00 1-216-298-00 1-247-741-11	CARBON	150 10K 2.2K 2.2 150	5%	1/10W 1/10W 1/10W 1/10W 1/2W	
	R061 R062 R064 R070 R071	1-216-079-00 1-216-242-00 1-216-091-00 1-216-055-00 1-216-063-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	18K 68K 56K 1.8K 3.9K	5% 5% 5% 5%	1/10W 1/8W 1/10W 1/10W 1/10W		R205 R206 R207 R301 R302	1-216-077-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	27K 270 2.2 15K 220	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R072 R075 R076 R077 R078	1-216-049-00 1-216-248-00 1-216-198-00 1-216-077-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1 K 120 K 1 K 15 K 1 K	5% 5% 5%	1/10W 1/8W 1/8W 1/10W 1/10W		R303 R304 R305 R306 R307	1-216-059-00 1-216-077-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220 220 220 2.7K 15K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R079 R081 R082 R083 R084	1-216-049-00 1-216-198-00 1-216-049-00 1-216-065-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 1K 1K 4.7K 2.2K	5%	1/10W 1/8W 1/10W 1/10W 1/10W		R308 R309 R310 R311 R312	1-216-049-00 1-216-051-00 1-216-174-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.8K 1K 1.2K 100		1/10W 1/10W 1/10W 1/10W 1/8W 1/8W	
	R086 R087 R089 R094 R095		METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 120 3.9K 15K 4.7K	5% 5%	1/10W 1/10W 1/8W 1/10W 1/10W			1-216-174-00 1-216-025-00 1-216-047-00 1-216-089-00 1-216-202-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 100 820 47K 1.5K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/8W	
	R096 R097 R099 R100 R101	1-216-017-00 1-216-069-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 33K 18K 47 6.8K	5% 5% 5% 5%	1/10W 1/10W 1/8W 1/10W 1/10W		R319 R320 R321 R322	1-216-057-00 1-216-023-00 1-216-053-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.2K 82 1.5K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R102 R103 R104 R105 R106	1-216-061-00 1-216-057-00 1-216-057-00 1-216-109-00 1-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3.3K 2.2K 2.2K 330K 22K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R323 R324 R325 R326 R327	1-216-192-00 1-216-065-00 1-249-410-11 1-216-035-00 1-216-121-00	METAL GLAZE CARBON METAL GLAZE METAL GLAZE METAL GLAZE	560 4.7K 270 270 1M	5% 5% 5% 5% 5% 5% 5%	1/8W 1/10W 1/4W 1/10W 1/10W	
	R107 R108 R109 R110 R111	1-216-073-00 1-216-049-00 1-216-190-00 1-249-437-11 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE CARBON METAL GLAZE	10K 1K 470 47K 33K	5% 5% 5% 5%	1/10W 1/10W 1/8W 1/4W 1/10W		R328 R329 R330 R331 R332	1-216-001-00 1-216-109-00 1-216-244-00 1-216-113-00 1-216-270-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10 330K 82K 470K 1M	5% 5% 5%	1/10W 1/10W 1/8W 1/10W 1/8W	
	R112 R113 R114 R115 R116	1-249-420-11 1-216-085-00 1-216-238-00 1-216-045-00 1-216-049-00	CARBON METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.8K 33K 47K 680 1K	5% 5% 5% 5% 5%	1/4W 1/10W 1/8W 1/10W 1/10W		R333 R334 R335 R336 R337	1-216-091-00 1-216-067-00 1-216-001-00 1-216-059-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	56K 5.6K 10 2.7K 10K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R118 R119 R130 R131	1-216-037-00 1-216-045-00 1-249-409-11 1-216-041-00	METAL GLAZE METAL GLAZE CARBON METAL GLAZE	330 680 220 470	5% 5% 5%	1/10W 1/10W 1/4W 1/10W		R338 R341 R342	1-216-073-00 1-216-061-00 1-216-041-00	METAL GLAZE METAL GLAZE METAL GLAZE	10K 3.3K 470	5% 5% 5%	1/10W 1/10W 1/10W	

RM-694

The components identified by shading and mark  $\hat{\Delta}$  are critical for safety. Replace only with part number specified.

REF.NO.	PART NO.					REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
R343 R346 R347 R348 R349	1-216-031-00 1-216-037-00 1-216-089-00 1-216-033-00 1-216-029-00	METAL GLAZE METAL GLAZE METAL GLAZE	180 330 47K 220 150	55%	1/10W 1/10W 1/10W 1/10W 1/10W		R523 R524 R525 R527 R532	1-216-099-00 1-216-065-00 1-215-869-11	CARBON  METAL GLAZE METAL GLAZE METAL OXIDE METAL GLAZE	1.5K 5% 120K 5% 4.7K 5% 1K 5% 22K 5% 3.3M 5%	1/2W 1/10W 1/10W 1W 1/10W	
R350 R351 R352 R353 R354	1-216-041-00 1-216-043-00 1-216-039-00 1-249-438-11 1-216-081-00	METAL GLAZE METAL GLAZE CARBON METAL GLAZE	390 56K 22K	555%			R533	1-216-133-00	METAL GLAZE	6.8K 5% 270K 5% 1K 5% 100 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R355 R356 R357 R360 R363	1-216-049-00 1-216-041-00 1-216-039-00 1-216-001-00 1-216-222-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 470 390 10 10K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/8W		R545 R548 R601 A	1-216-069-00 1-216-107-00 1-216-049-00 1-216-025-00 1-249-408-11 1-216-286-00 1-216-049-00 1-216-099-11 1-214-923-00 1-215-903-11	METAL GLAZE METAL GLAZE WIREWOUND CARBON METAL OXIDE	180 5% 4.7M 5% 1K 5% 3.3 5% 270K 5% 68K 5%	1/4W 1/8W 1/10W 10W F 1/2W	:
R364 R399 R402 R403 R404	1-216-222-00 1-216-037-00 1-216-172-00 1-216-023-00 1-216-023-00 1-216-023-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 330 82 82 82 82	5% 5%	1/10W		R605 <u>A</u>	1-247-752-11 1-247-752-11 1-218-265-91 1-212-877-11 1-249-430-11 1-215-884-11	METAL GLAZE FUSIBLE CARBON	1K 5% 8.2M 5% 68 5% 12K 5%	2W 1/2W 1W 1/4W 1/4W 2W	
R406 R407 R408 R409	1-216-226-00 1-216-226-00 1-216-091-00 1-216-023-00 1-216-037-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	15K 15K 56K 82	55555555555555555555555555555555555555	1/8W 1/8W 1/10W 1/10W		R609 R611 R612 R613	1-207-905-00	WIREWOUND CARBON FUSIBLE FUSIBLE	0.27 10%	2H	
R412 R413 R420 R421	1-216-037-00 1-216-037-00 1-216-182-00 1-216-449-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL OXIDE METAL GLAZE	330 330 330 220 56 82K	5% 5% 5% 5% 5%	1/10W 1/10W 1/8W 2W		R615 R617 R620 R621 R801	1-216-013-00 1-216-354-11 1-216-465-11 1-216-465-11 1-217-778-11	METAL GLAZE METAL OXIDE METAL OXIDE METAL OXIDE	33 5% 2.7 5% 27K 5% 27K 5% 1K 5%	1/10W 1W F 2W 2W	
R424 R425 R426 R427	1-216-222-00 1-216-033-00 1-216-045-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 220 680 1K	5% 5% 5% 5% 5% 5%	1/8W 1/10W 1/10W 1/10W		R802 R803 R804 R805 R806	1-217-819-51 1-216-352-11 1-216-013-00 1-216-065-00 1-216-049-00	FUSIBLE METAL OXIDE METAL GLAZE METAL GLAZE	2.7K 5% 1.8 5% 33 5% 4.7K 5%	1/4W 1W F 1/10W 1/10W 1/10W	
R430 R431 R432 R433	1-216-077-00 1-216-077-00 1-249-403-11 1-216-079-00	METAL GLAZE METAL GLAZE CARBON METAL GLAZE		5%%%%%% 5555555555			R807 R808 R809 R810	1-216-045-00 1-216-091-00 1-216-748-11 1-216-109-00 1-216-069-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 5% 56K 5% 39K 5% 330K 5% 6.8K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R437 R501	1-216-089-00 1-216-085-00 1-216-214-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	33K 4.7K	555555	1/10W 1/10W 1/10W 1/8W		R812 R813 R814 R816	1-215-869-11 1-212-877-11 1-215-868-00 1-247-883-00	METAL OXIDE FUSIBLE METAL OXIDE CARBON	1K 5% 68 5% 680 5% 150K 5%	1W F 1/4W 1W F 1/4W 1/10W	
R502 R503 R504 R505 R507	1-247-743-11 1-249-437-11 1-216-017-00 1-216-073-00 1-216-350-11	CARBON CARBON METAL GLAZE METAL GLAZE METAL OXIDE	220 47K 47 10K 1.2	5% 5% 5% 5%	1/2W 1/4W 1/10W 1/10W 1W F		R817 R818 R819 R820 R821	1-216-071-00 1-202-830-00 1-249-448-11 1-217-811-11 1-216-059-00	METAL GLAZE SOLID CARBON FUSIBLE METAL GLAZE	8.2K 5% 10K 10% 1.2 5% 0.47 5% 2.7K 5% 1.8K 5%	1/2W 1/4W F 1/4W 1/10W	
R508 R510 R511 R512 R513	1-215-867-00 1-216-061-00 1-216-244-00 1-216-089-00 1-216-053-00	METAL OXIDE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470 3.3K 82K 47K 1.5K	5% 5% 5% 5%	1/10W 1/8W 1/10W 1/10W		R823 R826 R827 R830	1-216-204-00 1-216-077-00 1-216-025-00 1-216-081-00 1-216-192-00 1-215-882-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	15K 5% 100 5% 22K 5% 560 5%	1/8W 1/10W 1/10W 1/10W 1/8W 2W F	
R514 R515 R516 R517 R518	1-216-051-00 1-216-683-11 1-216-095-00 1-216-031-00 1-216-295-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	1.2K 22K 82K 180 0	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	1 1 1 1 1 1 1 1	R850 R1301 R1302 R1303 R1304 R1305	1-215-882-00 1-216-025-00 1-216-029-00 1-216-039-00 1-216-200-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	22 5% 100 5% 150 5% 150 5% 390 5% 1.2K 5%	2W F 1/10W 1/10W 1/10W 1/10W 1/8W	
R519 R520 R521 R522	1-216-049-00 1-216-258-00 1-216-053-00 1-215-863-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL OXIDE	1K 330K 1.5K 100	5% 5% 5% 5%	1/8W 1/10W 1/10W	! ! : !	R1306	1-216-059-00 1-216-047-00	METAL GLAZE METAL GLAZE	2.7K 5% 820 5%	1/10W 1/10W	



The components identified by shading and mark  $\triangle$  are critical for safety. Replace only with part number specified.

REF.NO. PART NO.	DESCRIPTION		REMARK	REF.NO	. PART NO.	DESCRIPTION	<b>∤</b> -		REMARI
R1308 1-216-045-00 R1309 1-216-049-00 R1310 1-216-047-00	METAL GLAZE 1K METAL GLAZE 820	5% 1/10V 5% 1/10V 5% 1/10V	ł ł	C703		PACITOR> CERAMIC CHIP	' 330PF	5%	50V
R1311 1-216-065-00 R1312 1-216-222-00 R1313 1-216-025-00	METAL GLAZE 4.7K	5% 1/10¥ 5% 1/8₩		C704 C705 C706 C707	1-163-007-11 1-163-191-00 1-163-007-11 1-162-116-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC	680PF 270PF 680PF 680PF	10% 5% 10% 10%	50V 50V 2KV
<vaf< td=""><td>NIABLE RESISTOR&gt;</td><td></td><td></td><td>C708 C709 C710</td><td>1-162-114-00 1-163-007-11</td><td>CERAMIC CERAMIC CHIP ELECT</td><td>680PF 10MF</td><td>10% 20%</td><td>2KV 50V 250V</td></vaf<>	NIABLE RESISTOR>			C708 C709 C710	1-162-114-00 1-163-007-11	CERAMIC CERAMIC CHIP ELECT	680PF 10MF	10% 20%	2KV 50V 250V
RV001 1-238-012-11 RV331 1-238-012-11 RV501 1-238-016-11 RV502 1-226-703-11 RV503 1-238-019-11	RES, ADJ, CARBON 1 RES, ADJ, CARBON 1 RES, ADJ, CARBON 1 RES, ADJ, METAL GL RES, ADJ, CARBON 4	AZE 10K		C714 C716	1-163-129-00 1-124-360-00 1-162-622-11		1000MF	5% 20% 10% 10%	50V 16V 400V 50V
RV504 1-238-019-11 RV505 1-238-009-11 RV801 1-238-015-11	RES, ADJ, CARBON 4 RES, ADJ, CARBON 2 RES, ADJ, CARBON 2	7K 20 . 7K		C718 C719	1-162-622-11 1-163-005-11 1-163-005-11 1-163-005-11	CERAMIC CHIP	470PF 470PF	10%	50V 50V
RV802 1-238-019-11	RES, ADJ, CARBON 4	7K			<c0n< td=""><td>NECTOR&gt;</td><td></td><td></td><td></td></c0n<>	NECTOR>			
<s\\'1< td=""><td>TCH&gt;</td><td></td><td></td><td>  CNC71   CNC72   CNC81</td><td>*1-508-786-00 *1-568-881-51 *1-560-123-00</td><td>PIN, CONNECT</td><td>OR 6P</td><td></td><td></td></s\\'1<>	TCH>			CNC71   CNC72   CNC81	*1-508-786-00 *1-568-881-51 *1-560-123-00	PIN, CONNECT	OR 6P		
S003 1-571-532-21	SWITCH, TACTIL SWITCH, TACTIL SWITCH, TACTIL			CNC82	*1-508-765-00	PIN, CONNECT	OR (5MM PIT	CH) 3P	
S601 A.1-571-433-12	SWITCH, PUSH (AC PI	JWER)		D702		•	ν		
<spa SG801 1-519-422-11</spa 	RK GAP> GAP, SPARK			D702 D703 D704 D705 D706	8-719-400-18 8-719-400-18 8-719-400-18 8-719-400-18 8-719-400-18	DIODE MA152W DIODE MA152W DIODE MA152W	K K K		
<tra< td=""><td>NSFORMER&gt;</td><td></td><td></td><td>D707</td><td>8~719-400-18</td><td>DIODE MA152W</td><td>K</td><td></td><td></td></tra<>	NSFORMER>			D707	8~719-400-18	DIODE MA152W	K		
T601 <u>A</u> 1-449-275-12 T603 <u>A</u> 1-421-776-11 T604 <u>A</u> 1-424-078-11 T605 <u>A</u> 1-424-391-11	S.R.T LFT TRANSFORMER, TRIGGE	ER PULSE	• •	D708 D709 D710 D711	8-719-400-18 8-719-400-18 8-719-400-18 8-719-300-33	DIODE MA152WI DIODE MA152WI	K K		
T801 1-437-090-00 T802 A. 1-439-416-51	HDI			: D/14	8-719-800-76 8-719-800-76 8-719-800-76	DIODE 1SS226	( ·		
<the< td=""><td>RMISTOR&gt;</td><td></td><td></td><td>i ! ! !</td><td><jac< td=""><td>K&gt;</td><td></td><td></td><td></td></jac<></td></the<>	RMISTOR>			i ! ! !	<jac< td=""><td>K&gt;</td><td></td><td></td><td></td></jac<>	K>			
THP601 <u>↑</u> , 1-808-059-32	THERMISTOR, POSITI	VE		J701	1-526-990-11	SOCKET, PICT	URE TUBE		
<tux< td=""><td>ER&gt;</td><td></td><td></td><td>1 1 1 1</td><td>&lt;01</td><td>L&gt;</td><td></td><td></td><td></td></tux<>	ER>			1 1 1 1	<01	L>			
TU101A, 1-465-541-11	TUNER (BT-3C 301)		· · · · · ·	L704	1-410-878-11	INDUCTOR	33UH	,	
<cry?< td=""><td>STAL&gt;</td><td></td><td></td><td></td><td><tra< td=""><td>NSISTOR&gt;</td><td></td><td></td><td></td></tra<></td></cry?<>	STAL>				<tra< td=""><td>NSISTOR&gt;</td><td></td><td></td><td></td></tra<>	NSISTOR>			
X331 1-567-307-11 X332 1-567-131-00	VIBRATOR, CRYSTAL OSCILLATOR, CRYSTAL OSCILLATOR, CRYSTAL			Q702 Q703 Q704 Q705 Q706	8-729-200-17 8-729-230-49	TRANSISTOR 25 TRANSISTOR BETTANSISTOR 25 TRANSISTOR 25 TRANSISTOR BETTANSISTOR BETT	7871 5A1091-0 5C2712-YG		
<pre><teri ************************************<="" 1-565-666-12="" td="" yc1301=""><td>·</td><td></td><td></td><td>Q707 Q708 Q709 Q710</td><td>8-729-200-17 \$-729-230-49 8-729-906-70 8-729-200-17</td><td>TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR BE TRANSISTOR 2S</td><td>SC2712-YG S871</td><td></td><td></td></teri></pre>	·			Q707 Q708 Q709 Q710	8-729-200-17 \$-729-230-49 8-729-906-70 8-729-200-17	TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR BE TRANSISTOR 2S	SC2712-YG S871		
A-1638-016-A	C BOARD, COMPLETE	* *			<res.< td=""><td>ISTOR&gt;</td><td></td><td></td><td></td></res.<>	ISTOR>			
*4-379-160-01 *4-379-167-01	COVER (REAR LID), COVER (MAIN), CV	v		JR1 JR2	1-216-296-00 1-216-296-00		0 5% 0 5%	1/8₩ 1/8₩	

The components identified by shading and mark  $\triangle$  are critical for safety. Replace only with part number specified.



REF.NO.	PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
	1-216-296-00		0	5% 5%	1/8W 1/8W		C5	1-124-120-11		220MF	20%	167
IPA	1-216-296-00 1-216-296-00 1-216-296-00 06-216-296-00	METAL GLAZE	0 0	5% 5% 5% 5%	1/8W 1/8W 1/8W		C6 C7 C8 C9	1-163-235-11 1-163-235-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.1MF 22PF 22PF 22PF	5% 5% 5%	25V 50V 50V 50V
JR13 JR14 JR15	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5% 5% 5% 5%	1/8W 1/8W 1/8W 1/8W 1/8W		C10 C11 C12 C13	1-163-038-00 1-163-038-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.1MF 0.1MF 0.1MF		25V 25V 25V 25V
R704 R705	1-216-296-00 1-216-296-00 1-216-487-11 1-202-824-00 1-216-182-00	METAL GLAZE METAL GLAZE METAL OXIDE SOLID METAL GLAZE	0 0 12K 3.3K 220	5% 5% 5% 10% 5%	1/8W 1/8W 3W 1/2W 1/8W	F	C14 C16 C17 C23	1-124-927-11 1-163-117-00 1-163-117-00 1-124-927-11	CERAMIC CHIP		20% 5% 5% 20%	50V 50V 50V 50V
	1-247-822-11	•	430		1/4W		; † †	<con< td=""><td>NECTOR&gt;</td><td></td><td></td><td></td></con<>	NECTOR>			
R708 R709 R711	1-249-401-11	CARBON SOLID	47 330K 5.6K 1K	5% 5% 10% 5% 5%	1/4W 1/2W 1/10W 1/8W		CNV1 CNV2	*1-565-393-11 *1-565-393-11	CONNECTOR, BO	DARD TO BO DARD TO BO	ARD ARD	
R713	1-215-469-00 1-216-487-11	METAL METAL OXIDE	100K 12K	1% 5%	1/4W 3W	F	1 	< DIO	DE>			
R715 R716	1-202-824-00 1-216-182-00	SOLID	3.3K 220 680	10% 5% 5%	1/2W 1/8W 1/4W		D1 D3 D5 D6	8-719-400-18	DIODE DAP2021 DIODE DAP2021 DIODE MA152W	<b>(</b> (		
R719 R720 R721	1-202-814-11 1-216-166-00 1-216-210-00 1-202-842-11 1-202-848-00	METAL GLAZE	47 3.3K	10%	1/2W 1/8W 1/8W 1/2W 1/2W		D9	8-719-106-17 <ic></ic>	DIODE RD6.8M	·B2		
R724 R725 R726	1-216-198-00 1-202-846-00 1-202-838-00 1-202-824-00	SOLID SOLID SOLID	1K 470K 100K 3.3K	10% 10% 10%	1/8W 1/2W 1/2W 1/2W		102 103	8-759-515-59 8-759-510-49 <coii< td=""><td>IC FCB61C65L-</td><td>-70P</td><td></td><td></td></coii<>	IC FCB61C65L-	-70P		
R729 R730 R731	1-249-409-11 1-216-347-11 1-249-416-11 1-216-166-00 1-216-061-00 1-216-194-00	METAL OXIDE CARBON METAL GLAZE METAL GLAZE	0.68 820 47 3.3K 680		1/4W 1W 1/4W 1/8W 1/10W 1/8W	F	L1 L2 L3 L4	1-408-407-00	INDUCTOR	3.3UH 6.8UH 6.8UH 6.8UH		
R733	1-216-194-00	METAL GLAZE	680 100	5%	1/8W			<01>		NAC TO A	. Species	
R735	1-249-405-11 1-215-493-00 1-216-487-11 1-215-483-00	METAL METAL OXIDE	100 1M 12K 390K	1% 5%	1/4W 1/4W 3W 1/4W	F	,PS1 <u>A</u>	. 1-532-679-91 <tra <="" td=""><td>LINK, IC∺(ICF √SISTOR&gt;</td><td>/-N15) (U.6.</td><td>A STATE</td><td></td></tra>	LINK, IC∺(ICF √SISTOR>	/-N15) (U.6.	A STATE	
	1-216-198-00		1 K	5%	1/8W		Q1	8-729-900-53	TRANSISTOR DI	C114EK		
		IABLE RESISTOR	>				Q2 Q3 Q4 Q5	8-729-120-28 8-729-120-28	TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S	C1623-L5L C1623-L5L	6	
RV702 RV703 RV704	1-230-619-11 1-237-749-11 1-237-749-11	RES, ADJ, MET RES, ADJ, MET RES, ADJ, CAR RES, ADJ, CAR	AL GLA BON 22 BON 22	ZE 110 00 00	M		Q6 Q7 Q9 Q10	8-729-807-87 8-729-901-04 8-729-901-01	TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR DT TRANSISTOR DT	B1295-UL6 A114EK C144EK		
		**************************************					Q11	8-729-901-01	IN MUICICHANI	C144CN		
	n 1040-020-A	***********		n: #41	TIN OUL	• • •		<res1< td=""><td>STOR&gt;</td><td></td><td></td><td></td></res1<>	STOR>			
C1	<cap< td=""><td>ACITOR&gt;</td><td>100MF</td><td></td><td>20%</td><td>16V</td><td>JR01 JR02 JR03 JR08</td><td>1-216-295-00 1-216-295-00</td><td>METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE</td><td>0 5% 0 5% 0 5% 0 5% 0 5%</td><td>1/10V 1/10V 1/10V 1/10V</td><td>j J</td></cap<>	ACITOR>	100MF		20%	16V	JR01 JR02 JR03 JR08	1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/10V 1/10V 1/10V 1/10V	j J
C2 C3	1-163-038-00 1-124-120-11	CERAMIC CHIP	0.1MF 220MF		20%	25V 16V 50V	JR09 JR11	1-216-295-00	METAL GLAZE	0 5% 0 5%	1/10	V

# KV-M2140K/M2141K RM-694

V J1

The components identified by shading and mark  $\triangle$  are critical for safety.

Replace only with part number specified.

REF.NO. PART NO	. DESCRIPTION			REMARK	REF.NO. PART NO.			REMARK
JR13 1-216-2 JR14 1-216-2	96-00 METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/10W 1/8W 1/8W 1/8W 1/8W		<co! CN2001*1-568-878-51</co! 	NNECTOR>	3P	
JR17 1-216-2 JR18 1-216-2 JR19 1-216-2 JR20 1-216-2 JR21 1-216-2	96-00 METAL GLAZE 96-00 METAL GLAZE 96-00 METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/10W 1/8W 1/8W 1/8W 1/8W		<jac< td=""><td>JACK</td><td></td><td></td></jac<>	JACK		
JR23 1-216-29	95-00 METAL GLAZE 96-00 METAL GLAZE 96-00 METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/10W 1/10W 1/8W 1/8W 1/10W		<001 L2201 1-408-409-00	! NDUCTOR	10UH *************	:****
JR203 1-216-29 JR221 1-216-29	95-00 METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5% 470 5%	1/10W 1/10W 1/10W 1/10W 1/2W		<u>****</u> <u> </u>	MAGNET, DISK; 10 MAGNET, ROTATAB	DMM Ø	
R3 1-216-04 R4 1-216-02 R5 1-216-04	14-00 METAL GLAZE 49-00 METAL GLAZE 25-00 METAL GLAZE 47-00 METAL GLAZE 01-00 METAL GLAZE	4.7K 5% 1K 5% 100 5% 820 5% 10 5%	1/8W 1/10W 1/10W 1/10W 1/10W		1-452-277-00 1-503-258-21 <u>A.</u> 1-590-460-11 V901 <u>A.</u> 8-738-753-05	SPEAKER CORD, POWER (WI	TH CONNECTOR)	
R8 1-216-07 R9 1-216-30 R10 1-218-32	33-00 METAL GLAZE 71-00 METAL GLAZE 08-00 METAL GLAZE 25-11 METAL GLAZE 55-11 METAL GLAZE	27K 5% 8.2K 5% 4.7 5% 120 5% 120 5%	1/10W 1/10W 1/10W 1/4W 1/4W		**************************************		**************************************	
R12 1-218-32 R13 1-216-02 R14 1-216-00 R15 1-216-01 R16 1-216-01	01-00 METAL GLAZE 13-00 METAL GLAZE	120 5% 100 5% 10 5% 33 5% 33 5%	1/4W 1/10W 1/10W 1/10W 1/10W	 		POLISH/RUSSIAN)	- ION (ENGLISH/GERMA	EMARK 
R18 1-216-02 R19 1-216-02 R21 1-216-01	3-00 METAL GLAZE 55-00 METAL GLAZE 55-00 METAL GLAZE 3-00 METAL GLAZE 8-00 METAL GLAZE	33 5% 100 5% 100 5% 33 5% 56 5%	1/10W 1/10W 1/10W 1/10W 1/10W	, , , , ,	*4-200-681-01 *4-200-684-01	INDIVIDUAL CARTO CUSHION (UPPER) CUSHION (LOWER) BAG, PROTECTION	(ASSY)	
R40 1-216-06 R42 1-216-04	4-00 METAL GLAZE 5-00 METAL GLAZE 9-00 METAL GLAZE 9-00 METAL GLAZE		1/8₩ 1/10₩ 1/10₩ 1/10₩	! ! ! ! ! ! !	1-465-562-11	OTE COMMANDER CONTROL UNIT, RE COVER, BATTERY (	EMOTE (RM-694) (FOR RM-694)	
	<variable resistor<="" td=""><td>&gt;</td><td></td><td></td><td></td><td></td><td></td><td></td></variable>	>						
RV1 1-238-01	2-11 RES, ADJ, CAR	BON 1K						
X1 1-579-26	<pre><crystal> 6-21 CRYSTAL VIBRA</crystal></pre>	TOR						
**********	***********	*******	:*******	******				
<b>*</b> 1-638-16	7-11 J1 BOARD							
	<capacitor></capacitor>			i ! ! !				
C2200 1-164-23	2-11 CERAMIC CHIP	0.01MF	5	ov				